

Configuration du lecteur de code à barres Ms 5145

Enter/Exit Configuration Mode




Recall Defaults



Enter/Exit Configuration Mode



Enter/Exit Configuration Mode



Enter/Exit Configuration Mode

